

Solar Star Thermal Switch Installation Instructions

OVERVIEW The Solar Star Thermal Switch will turn off the Solar Star when the temperature in the attic is below 65° F (18° C) and will turn on the Solar Star when the temperature in the attic is greater than 85° F (29°C).

Note: The Thermal Switch should be installed prior to roof installation.

Step 1. Remove the fan blade from underside of roof mount vent. Pull straight up on fan hub until fan blade is free from the motor shaft. **(Diagram A)**

Step 2. Disconnect one lead wire from motor terminal **(Diagram B)**. Add Thermal Switch to disconnected lead wire. **(Diagram C)**

Step 3. Align notch in fan hub with motor shaft and replace fan blade. **(Diagram D)**

Return to the Solar Star Installation Instructions to complete installation.

Please read all warnings and instructions before beginning installation.

ADDENDUM TO PARTS LIST

1. Thermal Switch (Optional, Sold Separately) (1)

